

IMPERATIVELY set the clock with heating time slots. Our recommendation is 1 hour – 1 hour 30 minutes for dry and warm shoes.

**PLEASE NOTE if your room is not heated, you will have to allow additional time**

## INSTRUCTIONS FOR USE DRY SHOES / GLOVES HOT AIR MODEL DRY-6/9 OR MIXED DRY 4-5-6 PAIRS

### 1. GENERAL

#### *Introduction*

First of all, we thank you for the acquisition of this shoe/glove dryer from the brand QUADRALP which will give you complete satisfaction. The purpose of this manual is to provide the owner and user with effective and safe instructions for its use and maintenance.

#### *Notes*

In the interest of the further development of its products, the manufacturer gives itself the opportunity to improve this guide and to modify certain technical characteristics of its devices according to the evolution of the legal environment and the standards in force, without notice or obligations.

#### *Maintenance*

This shoe/glove dryer **should be placed on a flat floor.**

#### Recommendation for use

This device is easy to operate and does not require any special safety prescriptions. However, it is not recommended to use it without having read and understood the recommendations contained in this leaflet.

In order to get the most out of your device's features, we recommend that you:

1. Always keep this operating and maintenance manual of the device available, it is essential to observe the safety rules for the prevention of accidents

### IMPERATIVE OF USE

**DO NOT OPERATE THE APPLIANCE 24 HOURS A DAY**

**LABOUTIQUE.comEDUSKI**

by QUADRALP - 616 rue Louis Armand SAVOIE HEXAPOLE 73420 MERY

TEL 00 33 (0) 4.79.52.30.33 email : [quadralp@quadralp.com](mailto:quadralp@quadralp.com)

### 1. TECHNICAL SPECIFICATIONS

Drying for 6-9 OR 4-5-6 shoes and gloves depending on model.

Drying is carried out using a resistor and a fan. Maximum power following 1000 watts

### 2. HEATING IS STARTED WITH A RED ON/OFF SWITCH

### 3. DRYING MODE SETTING: 3 POSITIONS HOT AIR 500 WATTS – AMBIENT AIR 35W – HOT AIR 1000 W

### 4. LOCATION

The following rules must be observed:

5. Suitably ventilated and sheltered room
6. Drying well put on a straight floor



### 7. ELECTRICAL CONNECTION

The electrical connection of the appliance must be made in accordance with the standards in force. Important: the ground connection is mandatory. Power supply: 230 V single-phase.

Be careful, in order to avoid any malfunction and damage to the shoe dryer, your electrical installation must be equipped with overcurrent protection. In addition, according to the NF-C15-100 standard, the dryer supply must be protected by a 30 MA differential circuit breaker installed at the head of the electrical installation.

### 1. COMMISSIONING

Setting the mechanical timer, with 1 or two time slots 1H TO 2H MAXIMUM



**REMINDER THE TIMER IS MANDATORY –**  
**Do not run the shoe dryer without the programmed timer, as the shoe dryer does not stop on its own.**

**1. SAFETY INSTRUCTIONS**

QUADRALP declines all responsibility in the event that anything other than shoes or gloves is suspended.

The device must be unplugged before any intervention requiring the disassembly of the rear part of the dryer. This intervention must be carried out by qualified personnel who are informed of the risks associated with electricity, or by the QUADRALP after-sales service.

**1. ANNUAL MAINTENANCE**

Clean the outer surface of the appliance with a slightly damp cloth.

Clean and vacuum the ventilation grille

**When the shoe/glove dryer is left unused for long periods of time, we advise you to remove the timer from the socket.**

**1. WARRANTIES**

The device is guaranteed for 2 years parts and labor, **excluding travel.**

**1. TROUBLESHOOTING**

BREAKDOWN	SOURCE	TROUBLESHOOTING
The device is not working	The socket is not or not properly plugged in	Plug in the outlet
	The Timer Is Poorly Programmed	Check the programming Do not set the timer to ON but to clock
	The red switch is not engaged	Turn the switch to 1 and the light will come on.
Le thermostat Security Overheating is on OFF		Press the rearmament

Pièces détachées : Support tube –Tube-Câbles chauffant-Interrupteur-Fiche électrique avec fusible

**1- AVIS DE L'UNION EUROPEENNE**

Les produits sur lesquels est apposé le logo CE sont conformes aux dispositions réglementaires définies par l'annexe 1 de la directive européenne 89/392 modifiée et de la directive 73/23/CEE de la Communauté Européenne qui portent sur les basses tensions.